ORDER NO. SD83042445C1

Service Manual

DIGITAL

Digital Audio Processor
SV-100
[M], [MC]

T.C. Corp
10 North Main St
Wharton NJ 07885
www.servicemanuals.net

Areas

* [M] is available in U.S.A.
* [MC] is available in Canada.

Specifications

Specifications are subject to change without notice for further improvement.
Weights and dimensions shown are approximate.

■ General

Power supply: 3-way power supply (operating voltage DC 12 V)
120 V, AC, 60 Hz (using supplied AC power unit SH-V100)
DC 12 V (using optional battery pack LCS-2012P)
DC 12 V (using optional car battey cord PV-C34)
(only for cars with negative grounded 12 V battery)

Power consumption: 14 W
(DC 12 V) (SV-100)
40 W (using SH-V100)
With SH-V100 power switch off: 1.3 W

Dimensions: SV-100: 23.8 W×24 D×9.2 H cm
(9⅜"×9⁷⁄₁₆"×3⅝")
SH-V100: 7.8 W×24 D×9.2 H cm
(3¹⁄₁₆"×9⁷⁄₁₆"×3⅝")

Weight: SV-100: 2.9 kg (6.41 lbs) (net)
SH-V100: 2.3 kg (5.1 lbs)

■ System type

Type: Digital audio processor

PCM standard: Consumer PCM encoder/decoder standards file STC-007 of the EIAJ stereo technical committee, video technical committee.
(with recording pre-emphasis)

Quantization: 14-bit linear

Coding: 14-bit linear

Recording time: maximum 2 hours (using NV-T120E VHS video cassette.)

Number of audio channels: 2 (L, R stereo)

Frequency response: 2 Hz~20 kHz (±0.5 dB)

Total harmonic distortion: 0.01% or less (1 kHz, 0 dB)

Dynamic range: 86 dB or more

■ Input level and impedance

Line: 30 mV [at reference input level (−15 dB indication)]/50 kohm

Microphone: 0.7 mV [at reference input level (−15 dB indication)]/600 ohm

Video: 1 Vp-p/75 ohm

■ Output level and impedance

Line: 400 mV [at reference input level (−15 dB indication)]/600 ohm

Video: 1 Vp-p/75 ohm

Digital dubbing (copying): 1 Vp-p/75 ohm

■ Accessory functions:

VTR tracking check
Battery check
Rec mute
Rec/pb level indication
Playback mode switch
Playback muting
Playback indicator
Headphone level control
Digital copy jack

Technics

Matsushita Engineering and Service Company
50 Meadowland Parkway,
Secaucus. New Jersey 07094

Panasonic Hawaii Inc.
91-238 Kauhi St. Ewa Beach
P.O. Box 774
Honolulu, Hawaii 96808-0774

Matsushita Electric of Canada Limited
5770 Ambler Drive, Mississauga,
Ontario, L4W 2T3

Panasonic Sales Company, Division of Matsushita Electric of Puerto Rico, Inc.
Ave, 65 De Infanteria, KM 9.7
Victoria Industrial Park
Carolina, Puerto Rico 00630

■ CONTENTS

	Page
SAFETY PRECAUTION	2
COPY OUT TERMINAL	2
LOCATION OF CONTROLS	3
CONNECTIONS AND OPERATION	5
DISASSEMBLY INSTRUCTIONS	
Main unit	6
AC power unit	9
TROUBLE SHOOTING	10
CHECKING BY USE OF A TV SET	11
ABOUT VIDEO CASSETTES AND RECORDERS	12
MEASUREMENTS AND ADJUSTMENTS	13
CIRCUIT BOARDS AND WIRING CONNECTION DIAGRAM	18
BLOCK DIAGRAM	
Main unit	21
AC power unit	24
REPLACEMENT PARTS LIST	24
EXPLODED VIEWS	
Main unit	27
AC power unit	29
RESISTORS & CAPACITORS	29
PRINTED CIRCUIT BOARDS	32
HOW TO REPLACE CHIPS	41
PLAYBACK MODE SELECTION	41
PACKING	42
SCHEMATIC DIAGRAM	43

■ SAFETY PRECAUTION

1. Before servicing, unplug the power cord to prevent an electric shock.
2. When replacing parts, use only manufacturer's recommended components for safety.
3. Check the condition of the power cord. Replace if wear or damage is evident.
4. After servicing, be sure to restore the lead dress, insulation barriers, insulation papers, shields, etc.
5. Before returning the serviced equipment to the customer, be sure to make the following insulation resistance test to prevent the customer from being exposed to a shock hazard.

• INSULATION RESISTANCE TEST

1. Unplug the power cord and short the two prongs of the plug with a jumper wire.
2. Turn on the power switch.
3. Measure the resistance value with ohmmeter between the jumpered AC plug and each exposed metal cabinet part, such as screwheads antenna, control shafts, handle brackets, etc. Equipment with antenna terminals should read between 3MΩ and 5.2MΩ to all exposed parts. (Fig. A) Equipment without antenna terminals should read approximately infinity to all exposed parts. (Fig. B)

Note: Some exposed parts may be isolated from the chassis by design. These will read infinity.



(Fig. A)

Resistance = 3MΩ—5.2MΩ



(Fig. B)

Resistance = Approx ∞

4. If the measurement is outside the specified limits, there is a possibility of a shock hazard. The equipment should be repaired and rechecked before it is returned to the customer.

■ COPY OUT TERMINAL

When "COPY OUT" terminal of this unit is connected to "VIDEO IN" terminal of VCR, the rec/playback mode of this unit is automatically shifted to "playback" mode, and then recording is not possible.
Do not use "COPY OUT" terminal for purposes other than digital dubbing.

■ LOCATION OF CONTROLS

• Main unit



• Functions

1 Recording muting switch (rec mute)

Press when you want to record a blank space on the tape. Recording muting (no-signal recording) only takes place as long as this switch is kept depressed during recording.

2 Recording level control (rec level)

Use to adjust recording level.

3 Recording balance control (rec balance)

Used to adjust the balance between left and right channel recording level.
The "center" click-stop position is the standard setting.

4 Display panel

Depending on operating condition, the display gives the following kinds of indication.
When the indicator switch is at the "level" position, the display shows recording and playback level for the left and right channels. The playback indicator lights up during playback.
When this indicator switch is at the "tracking/batt" position, the left channel scale provides tracking check indication, while the right channel scale provides battery check indication.

5 Indicator switch

(indicator: level ■ ■ tracking/batt)

Used to change display function.

6 Playback mode switch

(playback mode: 1■ ■2)

Used to select the demodulation mode that best matches the playback signal characteristics of the VCR being used.

7 Playback muting switch

(playback/mute: auto■ ■off)

For normal playback, this switch is left at the "auto" position so that it automatically mutes the signal to minimize noise when dropouts (dirt or damage) appear on the tape.

8 Headphone level control (phones level)

Use to adjust headphone volume.

• AC power unit (SH-V100)


Video output jack [OUT (VCR)]
Video input jack [IN (SV-100)]
Video tuner input jack [IN (TUNER)]
Video tuner input jack [IN (TUNER)]
Video output cable [OUT (VCR)]
DC 12V output cord
AC power cord
DC +12V
SIG



■ CONNECTIONS AND OPERATION

• Connection for recording and playback/TV program recording and playback

Note:

The following explanations apply to connections with the Panasonic PV-5000VCR and PV-A200X video tuner.

1. In the connection diagram shown below, PV-5000 power is supplied from the PV-A200X or PV-A500 video tuner's power output cable, via the SH-V100 AC power unit's video output cable.
2. The AC power unit has a recording mode switch that lets you switch between PCM recording and video (TV) recording without having to change any connections.
3. For recording TV programs, set the SH-V100 AC power unit's front panel recording mode switch to the "video" position and then operate the video tuner and VCR as usual.
4. For video playback, set the PV-A200X or PV-A500 video tuner's antenna switch to the "video" position and press the VCR's play button.
5. To view TV programs, set the PV-A200X or PV-A500 video tuner's antenna switch to the "TV" position and turn on the TV.
6. If you do not have a video tuner, you can use the optional PV-A100 AC adaptor to allow PCM recording and playback as well as video playback (of recorded cassettes).
7. Connections are slightly different if using a monitor type TV (having a video output).



Connection for digital dubbing (copying) using two VCRs.

※ When not performing digital dubbing, be sure to unplug the video cord from the SV-100 copy out jack.

• Connection for recording and playback using a home (not portable) VCR

Note:

1. Use VCR's video input selector to switch between video (TV program) recording and PCM recording.
   Set to "camera" position for PCM recording. Set to "tuner" position for TV program recording. For details, see your VCR's operating instructions.
2. Some VCR's do not have a video input selector: instead, switching (to external input) is automatic when a plug is inserted in the VCR's video input jack. In this case, you must remove the plug from the video input jack if you want to record TV programs.



■ DISASSEMBLY INSTRUCTIONS (Main unit)

1. How to remove the cabinet

1. Remove the 2 setscrews **(Fig. 1 : ❶, ❷)** of the cabinet.
2. Remove the cabinet by slightly releasing the side-plates outwards. **(Fig. 1)**



Fig. 1

2. How to remove the bottom board

1. Remove the 4 setscrews (Fig. 2 : ❸ ~ ❻) of the bottom board.
2. Remove the bottom board by lifting it from the rear part. **(Fig. 2)**



Fig. 2

3. How to remove the front panel

1. Remove each knob of rec level, rec balance, phones level, indicator, playback mode and playback mute. **(Remove these knobs according to Sec. 4 "How to remove the knobs".)**
2. Remove the 5 setscrews **(Fig. 3 : ❼ ~ ⓫)** from the front chassis, and draw the front chassis in the direction of the arrow. **(Fig. 3)**
3. Pull out the 3 connectors **(Fig. 4 : ⓐ , ⓑ , ⓒ)** from the back of the front chassis.
4. Remove the 5 setscrews **(Fig. 4 : ⓬ ~ ⓰)** from the front panel.
5. Set it up by reversing the procedure.

4. How to remove the knobs

- **Removal of rec level, rec balance, and phone level knobs.**
  Stick the cellophane tape to the knob as in **Fig. 5**, and pull the tape to remove the knob. If it is hard to remove, cover the knob with cloth and pull out the knob by use of pincers or the like.
  (Take special care not to scratch the knob.)



Fig. 5

- **Removal of indicator, playback mode, and playback mute knobs.**

1. Prepare a strong thread like nylon yarn and an eyeleteer or small screwdriver.
2. Set the thread into the gap between the front panel and the knob sufficiently until it is caught by the knob.
3. Pull the thread to remove.



Fig. 6

T.C. Corp
10 North Main St
Wharton NJ 07885
www.servicemanuals.net



Fig. 3



Fig. 4

5. How to remove the shield case and P.C.B.

1. Remove the cabinet.
2. Remove the 4 setscrews **(Fig. 3)** of the shield case, and remove the shield case from the main body.
3. Remove the 6 setscrews of the shield case to pull out the shield case. **(Fig. 7)**
4. Release the 2 claws of the holder, and remove the holder.
5. To remove the synchronizing P.C.B., remove the 2 setscrews **(Fig. 7 : ⓳ , ⓴)** and pull it out in the direction of the arrow.
6. To remove the video P.C.B., remove the 2 setscrews **(Fig. 7 : ㉑ , ㉒)** and pull it out in the direction of the arrow.
7. To remove the digital P.C.B., remove the video P.C.B. and 2 latches **(Fig. 7 : ⓐ)**.
8. To remove the shield case, pull out the 7 connectors (terminal No. A3, A6, F2, F17, C2, JA1, JA2).



Fig. 7

6. How to remove the analog P.C.B.

1. Remove the cabinet and bottom board.
2. Remove the shield case.
3. Remove the front chassis and pull out connector (A7).
4. Remove the 2 setscrews **(Fig. 8 : ㉓ , ㉔)** and nut of the analog P.C.B. Then remove the P.C.B. as in **Fig. 8.**



Fig. 8

7. How to remove the display P.C.B.

1. Remove the analog P.C.B.
2. Remove the battery case. **(Refer to Sec. 8 "How to remove the battery case.")**
3. Remove the 3 setscrews **(Fig. 9 : ㉕ ~ ㉗)** of the display P.C.B. Then raise the P.C.B. as in **Fig. 9.**
4. Thus the circuit can be checked. If the P.C.B. has to be completely removed, pull out 15 connectors (terminal No. F1, F3 ~ F13, F15, F16, F18).



Fig. 9



Fig. 10

8. How to remove the battery case

1. Remove the cabinet.
2. Remove the shield case.
3. Remove the battery case setscrews (**Fig. 10 : 28 , 29**) and connector (F14).

9. How to remove the power supply P.C.B.

1. Remove the bottom board.
2. Remove the battery case.
3. Remove the 4 setscrews (**Fig. 10: 30 ~ 33**) to draw out the rear chassis.
4. Raise the rear chassis as in **Fig. 10** and remove the shield plate setscrews (10 pcs).
5. Remove the 2 setscrews (**Fig. 11 : 34 , 35**) of power supply P.C.B.



Fig. 11

■ DISASSEMBLY INSTRUCTIONS (AC power unit)

1. How to remove the cabinet

1. Remove the cabinet setscrew (**Fig. 12 : 36**).
2. Remove the cabinet, releasing the side-plates outwards by hands.
3. To fit the cabinet, first let the cabinet claw engage with the front panel.



Fig. 12

2. How to remove the front panel

1. Remove the cabinet.
2. Remove the front panel setscrews (**Fig. 13 : 37 , 38**) and shift it down in the direction of the arrow.
3. To fit the front panel, first let the bottom claw engage with the chassis.



Fig. 13

3. How to remove the fuse

1. Remove the cabinet.
2. Remove the fuse P.C.B. setscrews (**Fig. 14 : 39 , 40**) and fuse (F701).



Fig. 14

• How to remove the power transistor

1. Remove the cabinet.
2. Remove the power transistor setscrews (**Fig. 15 : 41**) as in **Fig. 15**.
3. Unsolder the transistor.



Fig. 15

■ TROUBLE SHOOTING

Check the connection of each instrument and knob position before repair, and use the table below.

Problem	Cause	Solution
Power is not supplied.	* Battery pack is dead. (If using battery pack) * AC power unit connection is not perfect. * AC power unit is defective. * Power supply circuit is defective.	* Change with AC power unit. * Completely connect DC 12V output cord. * Check output voltage of AC power unit. * Check power supply circuit.
No recording with video in rec mode.	* Video cassette lug is broken. * Switch of AC power unit is at "video". * Recording level is low. (When level indicator is not deflected.)	* Cover the hole in the cassette with tape. * Set it to "digital audio". * Adjust recording level watching the level indicator.

Problem	Cause	Solution
Neither recording nor playback are possible.	* VCR is defective. * The unit is out of order.	* Check VCR and unit with reference to **"Checking by use of a TV set"** given in the following.
Noise is made during playback. **Playback quality is poor.**	* Video cassette tape is defective. * Tracking adjustment is not sufficient. * VCR head area is stained. * Recording was made at VCR's EP or LP (long recording time) setting.	* Play another recorded tape. If playback is perfect, the previous tape is defective or recording conditions are bad. (It can also be checked by recording a picture on the tape to check for noise.) * Select either "1" or "2" of playback mode. Also, adjust tracking of the VCR used. * Clean the VCR's video head. * Make a new recording with the VCR set to the SP position.
Playback sound is distorted.	* Recording level is too high or low. * Analog circuit is defective.	* Select optimum recording level. * Check analog circuit.
With power ON, noise is made from radio and TV.	* Switching power supply and high frequency signal are handled in power supply circuit. So, there is slight leakage of high frequency signal.	* Keep the unit away from the tuner or radio. * Replace the indoor antenna with outdoor antenna.
Hum noise occurs.	* Power cord or fluorescent light is too close to the connection cord.	* Connect the power plugs of amplifier and AC power unit in opposite positions.
TV program recording is not possible.	* Switch of AC power unit is at "digital audio".	* Set it to "video".

■ CHECKING BY USE OF A TV SET

If recording and playback are not possible or noise is made during playback, it can be checked by using a TV to check whether the cause is in the unit or in video.

• Check of VCR

1. Record a picture on the VCR.
2. Play it on the TV. If the picture is normal, then the VCR is normal.
3. If noise is excessive on the picture, the possible causes are scratches on the tape, insufficient adjustment of tracking, and stains on VCR's head.

Note: Some noise may be sometimes made even when the VCR is used in LP mode. So be sure to set it to normal mode.

Tape is damaged if this kind of picture appears and cannot be corrected using tracking adjustment.

• Check of the unit

1. After PCM recording, play the video cassette on a TV.
2. If the picture is like **photo 1**, the tape is PCM-recorded, and normal. If it is like **photo 2**, the tape is not PCM-recorded and blank. The recording system may be defective.
3. If the picture is like **photo 3**, no signal is recorded on the tape. If this picture appears when the level indicator is deflected, the recording system of digital circuit may be defective. If this picture appears when the level indicator is not deflected, the recording system of analog circuit may be defective.
4. Check it by playing the PCM recorded video cassette tape.

Note: The rec-play selection of this unit is automatically made by detecting the input signal. therefore, make sure that the playback indicator on the front panel is ON during playback and OFF during recording before checking the playback or recording system as mentioned above.



(Photo 1)

Tape is PCM-recorded, and normal. (Normal)



(Photo 2)

Tape is not PCM-recorded, and blank. (No recording)



(Photo 3)

Tape is PCM-recorded but no signal is recorded. (No signal)

• To check whether the SV-100 is recording properly:

There are two connection methods that can be used to check whether this unit is recording signals properly.

[Procedure]

- Use the LINE IN or microphone input for the recording input signal.
- Adjust the recording level control of the SV-100 so the recording/playback level indicators rise and fall. At this time, the television screen should show the pattern shown above if the SV-100 is properly recording the input signal.

[How to connect]





■ ABOUT VIDEO CASSETTES AND RECORDERS

• For best results, use the same VCR (video cassette recorder) for both recording and playback.

The SV-100 is a digital audio processor. For PCM recording and playback, the SV-100 must be used with a VCR.
VHS, Beta, and U-vision (or U-matic) type VCR's can all be used. However, new VCR models keep appearing on the market and there may be some that do not provide satisfactory performance in combination with this unit. Therefore, we recommend that you consult with your dealer and, if possible, try using the VCR with the SV-100 before making any buying decisions. For optimum results, the same VCR should be used for recording and playback.

- On the average, a typical video cassette tape can be used about 300 times (for recording and playback). If the same tape is used too many times, magnetic surface wear and tape stretch may interfere with normal playback. However, how many times a tape can be used depends on tape quality, VCR used, and the environment,
- Because video playback is seen by the human eye as a continuously moving picture, dropouts are rarely noticeable. However, in PCM recording and playback, dropouts can cause noise because they interfere with correct retrieval of the digital signal information. Of course, error correction circuitry and playback muting serve to minimize this problem. But the point is that tape quality is much more important for PCM recording and playback than it is for video.
- Therefore, for PCM recording it is recommended that you use the best quality video cassettes possible and if they are not new they should have been used only a few times.
- Clean the video heads from time to time. Good PCM recordings cannot be made if the heads are dirty.
- For best PCM recording and playback results, it is recommended that you use HG (high grade) VHS video cassettes.

■ MEASUREMENTS AND ADJUSTMENTS

- **Adjustment points**



Fig. 16



Note: No cable should be connected to LINE IN and VIDEO IN terminals.

Fig. 19

- **Display**

Indicator selector . . . . . "level"



Fig. 17

Indicator selector. . . . . "tracking/batt"



Fig. 18

1. Adjustment of output voltage (+5V)

After repair of the power supply circuit, adjust the output voltage according to the following procedure.

- **Instruments used and the condition of the set**

1. Electronic DC voltmeter.
2. Connect AC power unit to the main unit.
3. Connect the DC voltmeter to the terminals of C133. **(Fig. 16 : C P.C.B.)**

- **Adjusting procedure**

Adjust VR101 so that the voltage is 5.1V ± 0.1V a few minutes after power ON. **(Fig. 16 : F P.C.B.)**

2. Adjustment of display circuit

After repair of the display circuit, adjust the circuit according to the following procedure.

- **Instruments used and the condition of the set**

1. Electronic AC voltmeter.
2. 400 Hz sine wave oscillator.
3. DC power source (11V, 1A).
4. Connect AC power unit (SH-V100).
5. Recording level . . . . . .maximum
6. Recording balance . . . . . .center
7. Indicator select switch . . . . . .level
8. Playback mode switch 1
9. Playback muting switch . . . . . .auto
10. Connect 400 Hz sine wave oscillator to LINE IN.
11. Connect electronic AC voltmeter to LINE OUT.

Note: For the high offset, high gain and low gain, the adjustments on both right and left channels are simultaneously made by one variable resistor. Therefore, one of the right and left channel segaments of the display lights up and the other channel segment dims. Make the adjustment on the basis of the segment that dims.

Step	Item	Parts adjusted	Adjusting procedure
1	High offset **(Note)**	VR607	① Adjust input so that output of LINE OUT is 252 ± 1 mV. ② Adjust VR607 so that −19 dB segment of display dims. **(See Fig. 17)**
2	High gain **(Note)**	VR604	① Adjust input so that output at LINE OUT terminal is 2.25V. ② Adjust VR604 so that 0 dB segment of display dims. **(See Fig. 17)**
3	Low offset	VR608 (right channel) VR609 (left channel)	① Adjust input so that output at LINE OUT terminal is 8 mV. ② Adjust VR608 (right channel) and VR609 (left channel) so that −50 dB segment of display lights up. **(See Fig. 17)**
4	Low gain **(Note)**	VR605	① Adjust input so that output at LINE OUT terminal is 160 mV. ② Adjust VR605 so that −23 dB segment of display dims. **(See Fig. 17)**
5	Recovery time	VR601	① Adjust input so that output at LINE OUT terminal is 2.25V. ② Cut off the input instantaneously and check the falls of right and left channels of display. ③ If there is a difference between the falls, adjust VR601.
6	Tracking fullscale	VR602	① Set the indicator select switch to "tracking/batt". ② Connect VIDEO IN terminal to VIDEO OUT terminal of SV-100. ③ Adjust VR602 so that full-scale segment of left channel of display lights up. **(See Fig. 18)**
7	Battery empty level	VR603	① Pull out DC input terminal and connect DC power supply to battery terminal (F14). **(See Fig. 16 : F P.C.B.)** ② Adjust so that output of DC power supply is 11V. ③ Adjust VR603 so that E (battery) segment of right channel of display lights up. **(See Fig. 18)**

3. Offset adjustment

After repair of digital circuit, adjust the offset according to the following procedure.

- **Instruments used and the conditions of the set**

1. Oscilloscope (100 MHz).
2. Connect AC power unit (SH-V100).
3. Recording level . . . . . .minimum.
4. Connect the oscilloscope to VIDEO OUT terminal.
5. Keep LINE IN terminal open.
6. Make sure that the set is in recording mode. (Playback indicator should light up.)

Note: If input is applied to VIDEO IN terminal, the circuit is automatically shifted to playback mode.

- **Adjustment procedure**

Adjust VR401 (left channel) and VR402 (right channel) so that there are 3 bits from the last bit (LSB) of right/left channel of video output waveform. **(See photo 4, 5)**

4. PLL lock adjustment

After repair of digital circuit, adjust the PLL lock according to the following procedure.

- **Instruments used and the condition of the set**

1. Electronic DC voltmeter.
2. Video deck or home VCR.
3. Connect AC power unit (SH-V100).
4. Connect electronic DC voltmeter to terminal 1 of IC426.
5. Connect the video input terminal, and play the recorded tape.
6. Make sure that the set is in playback mode. (The playback indicator should light up.)

- **Adjusting procedure**

Adjust TC401 so that DC voltmeter is 2.5V ± 0.1V.

5. Synchronizing circuit adjustment

After repair of synchronizing circuit, adjust the circuit according to the following procedure.

- **Instruments used and the condition of the set**

1. Two-channel oscilloscope (100 MHz with delay).
2. TV SG or SV-100, SV-P100.
3. Connect AC power unit.
4. Connect VIDEO OUT and DIGITAL OUT terminals of TV SG (output 75 ohms, 1Vp-p) or SV-100 and SV-P100 to VIDEO IN terminal. **(See Fig. 19)**
5. Make sure that the set is in playback mode. (The playback indicator should light up.)

- **Adjusting procedure**

1. Completely turn VR501 counterclockwise, and VR502 clockwise.
2. Connect CH1 and CH2 of oscilloscope to connector X1 terminal ⑫ (IC505 terminal ③) and connector X2 terminal ③ (IC522 terminal ⑤).
3. Make sure that the waveform of each photo is like **photo 6**.

- **Good example** There are 3 bits rising.



(Photo 4)

- **Bad example** There are more than 3 bits rising.



(Photo 5)



(Photo 6)

4. Connect CH1 and CH2 of oscilloscope to connector X3 terminal ④ (IC518 terminal ④) and terminal ⑤ (IC522 terminal ④).
5. Adjust VR501 so that the waveform of each terminal is like **photo 7**.
   . . . . . Synchro adjustment 1 (VSC)
6. Connect CH1 and CH2 of oscilloscope to connector X3 terminal ⑥ (IC507 terminal ④) and terminal ⑤ respectively.
7. Adjust VR502 so that the waveform of each terminal is like **photo 8**.
   . . . . . Synchro adjustment 2 (V8)

- **Good example** 5.7 ± 1.5μsec



- **Bad example** More than 5.7 ± 1.5μsec



(Photo 7)

- **Good example** 33.4 ± 1.5μsec.



- **Bad example** More than 33.4 ± 1.5μsec



(Photo 8)

6. Video tracking adjustment

Watch the indication on the left channel section of the display panel and switch the playback mode back and forth between "1" and "2", while gradually turning the VCR's tracking adjustment, knob back and forth. Select the playback mode and VCR tracking knob setting that gives the furthest indications to the right.



- Optimum results are obtained if the indication reaches all the way into the orange section; however, you can still enjoy satisfactory playback if indication remains in the blue section. Tracking is poor if indication does not reach the blue section.

Note:

- If you cannot obtain good tracking by adjusting the VCR's tracking control and selecting optimum playback mode, the VCR's heads may be dirty or the cassette tape may be damaged. In this case, clean the video heads or try using a different cassette.
- When tracking is poor, playback muting will operate often, interrupting the playback sound; static-like noise may also occur.
- In extremely rare cases, noise may occur even if tracking is good. This is not necessarily a malfunction, it means that the limits of error correction function capability have been exceeded. To minimize the chances of such a problem, take good care of your VCR and video cassettes.

■ CIRCUIT BOARDS AND WIRING CONNECTION DIAGRAM

Note: The whilte-on-black numbers in the diagram stand for the types of connector. For the connector part No., refer to the price list of repair parts on page 26.

• Discription of terminals

Mark	Description	Mark	Description
AD L	Lift channel signal converted from analog to digital	MUT LED	LED mute signal
AD R	Right channel signal converted from analog to digital	PB	Playback signal
		PB CRCK IN	Clock input to punch CRC in 16 bits
AC 3V	AC 3V filament drive power supply	RB CRCK OUT	Clock output to punch CRC in 16 bits
BAL VOL L	Left channel signal of balance volume	PB DATA	Playback data
BAL VOL R	Right channel signal of balance volume	PB LED	Playback LED signal
B1 ~ B22	Segment terminal of display (FL601)	PB MUT EN	Playback muting ending signal
		PH RST	Headphone output reset signal
COM	Common terminal of power switch	PLL DIV	Frequency dividing signal of PLL
CRC	CRC (error correction) signal	PW ON	Power switch "ON" terminal
CRCK	Signal at "L" only in CRC range	REC/PB	Rec/playback selecting signal
C SYNC	Inverse signal of composite synchronizing	REC VOL L	Left channel recording volume signal
C SYNC IN	Input terminal of C SYNC	REC VOL R	Right channel recording volume signal
C SYNC OUT	Output terminal of C SYNC	RL SEL	Right/left channel selecting signal
DA L	Left channel signal converted from digital to analog	S 12V	Speedy 12V
		SC	Display scale indication terminal
DAR	Right channel signal converted from digital to analog	T CK	Test clock
		TRACK	Tracking signal
DISP MUT	Display mute signal	V EQ	Waveform equalizing control signal
EMPHA	Inverse signal of emphasis	VIDEO IN	Video input signal
F	Filament terminal of display	VIDEO OUT	Video output signal
FROM HP L	Left channel headphone amp input signal	V SYNC	V pulse of video signal
FROM HP R	Right channel headphone amp input signal	V OSC	V pulse signal synchronized with V SYNC
GND	Ground (earth)	VIDEO V	Vertical synchronizing signal
LINE IN L (L IN L)	Left channel line input signal	1G ~ 2G	Grid terminal of display
LINE IN R (L IN R)	Right channel line input signal	+12V	+12V line
LINE OUT L (L OUT L)	Left channel line output signal	+5V	+5V line
LINE OUT R (L OUT R)	Right channel line output signal	–5V	–5V line
MCK	Master clock (15.86 MHz)	–15V	–15V line
MUT	Mute signal		



■ BLOCK DIAGRAM

- Main unit



- **AC power unit**



■ REPLACEMENT PARTS LIST

Notes:
1. Part numbers are indicated on most mechanical parts. Please use this part number for parts orders.
2. Important safety notice: Components identified by ⚠ mark have special characteristics important for safety. When replacing any of these components use only manufacturer's specified parts.
3. Bracketed indications in Ref. No. columns specify the area. Parts without these indications can be used for all areas.
4. The "Ⓢ" mark is service standard parts and may differ from production parts.

Areas
* [M] is available in U.S.A.
* [MC] is available in Canada.

- **Main unit**

Ref. No.		Part No.	Description
INTEGRATED CIRCUITS			
IC101		SVIUPC494C	Power Supply OSC Control
IC151,152,155,157		SVINJM4559DS	Mic Amp,Pre-emphasis,Buffer
IC153,156		SVIUPD4066BC	Quad Bilateral Switch
IC154		SVITL082CP	Buffer
IC158,159		SVILA4140A	Phones Amp.
IC160		AN6914	Comparator
IC301		MN1400PCA	Slice Level Control
IC302,304		SVIHD74LS123	Multivibrator
IC303		SVIHD74LS74P	D-Type Flip Flop
IC305		SVIHD74LS00P	2-Input Positive NAND Gate
IC307		SVITC4001BP	2-Input Positive NOR Gate
IC308,309		SVINJM082D	Operational Amp.
IC310		AN6552F	Comparator
IC311,314		AN6914	Comparator
IC312,313		SVILM360N	Comparator
IC401,402,406		SVITL081CP	Operational Amp.
IC403,407,410		SVINJM082D	Operational Amp.
IC404,405,409		SVIUPD4066BC	Quad Bilateral Switch
IC408		SVITC40H074	D-Type Flip Flop
IC411		EHKMA6196	A-D/D-A Converter
IC412,420		SVIHD74LS126	Buffer
IC413,415		SVIHD74LS74P	D-Type Flip Flop
IC414		DN74LS04	Inverter
IC416		MN6603	REC/PB Control
IC417		MN6601	Recording LSI
IC418,419,424,425		SVIHM6116P-4	RAM
IC421		SVIHD74LS86P	2-Input Exclusive OR Gate
IC422		SVIHD74LS00P	2-Input Positive NAND Gate
IC423		MN6602	Playback LSI
IC426		SVISN74LS629	Voltage-Controlled OSC
IC427		SVITC5081AP	Phase-Controlled Comparator
IC481		SVIM74LS123P	Multivibrator
IC482		SVIHD74LS74P	D-Type Flip Flop
IC483		SVIHD74LS02P	2 Input NOR Gate
IC501		SVITC5081AP	Phase-Controlled Comparator
IC502,513,519,520		SVIHD74LS74P	D-Type Flip Flop
IC503,506,507,508		SVISN74LS123	Multivibrator
515,517,518			
IC504		DN74LS08	2-Input AND Gate
IC505		SVIHD74LS32P	2-Input OR Gate
IC509		MN4066B	Quad Bilateral Switch
IC510		SVIHD74LS00P	2-Input NAND Gate
IC511		SVIHD74LS11P	3-Input AND Gate
IC512,521		DN74LS02	2-Input NOR Gate
IC514		SVIHD74LS161	4-Bit Binary Counter
IC516		SVITC40H004P	Inverter
IC522		DN74LS14	Inverter
IC523		SVIM74LS160P	4-Bit Binary Counter
IC601		AN6552F	Operational Amp.

Ref. No.		Part No.	Description
INTEGRATED CIRCUITS			
IC602		AN6562	Operational Amp.
IC603,604		SVINJM082D	Operational Amp.
IC605,606		AN6870N	FL Drive
IC607		SVIUPD4066BC	Quad Bilateral Switch
IC608		SVITC4011BP	2-Input NAND Gate
TRANSISTORS			
Q101		2SD1271-Q	Switching
Q102		2SB643	Amplitude Expander
Q103,104,105		2SD636	Switching
Q106		2SB641	Switching
Q151,152,159		2SD636	Muting & Relay Drive
Q153,154,155,156 165		2SB641	Switching
Q157,158		2SD636	Switching
Q160	Ⓢ	2SC1328-T	Relay Drive
Q161~164		2SC2385-G	Mic Amp.
Q301,304		2SC2377	Buffer
Q302,303,305,306 309,318,322,323		2SD636	Buffer&Switching
Q307,308,310,319		2SB641	Buffer&Switching
Q311		2SK301	Switching
Q401,402,406,407 412,413		2SD636	Switching
Q403,408,414,415 417		2SB641	Switching
Q404,405		2SD636	Switching
Q409		2SK301	Switching
Q501,502		2SB641	Switching
Q503		2SD636	Switching
Q601~604,607		2SD636	Buffer&Switching
Q605,606		2SD637	Switching
Q608		2SB641	Switching
Q609		2SB642	Switching
Q611,612		2SK301	Input Amp
DIODES			
D101,107		MA2240	Zener,24V
D102~105		SVDS2K20H	Rectifier
D106		SVDS3S3M	Rectifier
D108,109	Ⓢ	MA162A	Bias
D110		MA1100	Zener,10V
D131		SVDPR5531K	Rec Muting Indicator
D132		SVDPG5531KY	Playback Indicator
D140		SVDERC81004H	Switching
D151~159	Ⓢ	MA162A	Bias
D301~304, 308,309, 311,313~316	Ⓢ	MA162A	Switching
D306	Ⓢ	MA1051	Zener,5.1V
D312,401		MA26T0-A	Switching
D402		0A90A	Switching
D403	Ⓢ	RVDRD7R5FB	Zener,7.5V
D404~406	Ⓢ	MA162A	Switching
D407		MA1150	Zener,15V
D408~412	Ⓢ	MA162A	Switching
D515	Ⓢ	MA162A	Switching
D601,602,607, 609,610	Ⓢ	MA162A	Switching
D603	Ⓢ	RVDRD7R5FB	Zener,7.5V
D604	Ⓢ	MA1056	Zener,5.6V
Q605,606,608, 613~617		0A90A	Switching
D611,612		MA1150	Zener,15V
CRYSTAL			
X401		SVQ43U1586	15.86MHz Counter OSC
COILS and TRANSFORMERS			
L101		SLQ1204T300A	Line Filter
L102		SLQT10-100	Choke
L103~105		SLQT10-121	Choke
L106		ELET271KA	Choke
L107		SLQT10-560	Choke
L108		SLT12K10A	Base Drive Transformer
L109	⚠	SLT28K2A	Switching Transformer

Ref. No.		Part No.	Description
L151,152		ELET102KA	Line Filter
L301		ELB5F7	Low Pass Filter
L302,303		ELB5F043	Delay Line
L304~306		SLQ0930T300C	Balun
L601,602		ELET102KA	Choke
LPF151,152		EULBPF304	Low Pass Filter
VARIABLE RESISTORS			
VR101		EVM38GA00B14	Output Voltage Adjustment, 10kΩ(B)
VR201		EWCXGA001A15	Rec Level, 100kΩ(B)
VR202		EWGHFA053375	Rec Balance,
VR203		EVJRCA014AF5	Phones Level
VR401,402		EVN38CA00B24	Offset Adjustment, 20kΩ(B)
VR501,502		EVMG0GA01B54	Synchro adjustment, 50kΩ(B)
VR601		EVN38CA00B16	Recovery Time Adjustment, 1MΩ(B)
VR602		EVN38CA00B24	Tracking Full-scale Adjustment, 20kΩ(B)
VR603		EVN38CA00B23	Battery Empty Level Adjustment, 2kΩ(B)
VR604~606		EVN38CA00B14	High Gain,Low Gain,+16V Adjustments, 10kΩ(B)
VR607		EVN38CA00B15	High Offset Adjustment, 100kΩ(B)
VR608,609		EVN38CA00B25	Low Offset Adjustment, 200kΩ(B)
VARIABLE CAPCITOR			
TC401		ECVIZW50X32E	Trimmer,PLL Lock Adjustment
FLUORESCENT DISPLAY TUBE			
FL601		SSDQBG124Z	Level & Tracking /batt
RELAY			
RLY151		SSDYAG2223	Muting
SWITCHES			
S601	⚠	ESB6612	Power
S602		EVQQJR02K	REC Muting
S603~605		ESD14184	Indicator,Playback Mode and Playback Muting Switches
FUSE			
F1[M] only	⚠	XBA1F30NU14	3A,125V

- **AC power unit**

Ref. No.	Part No.	Description
INTEGRATED CIRCUITS		
IC701	SVIUPC305C	Reference Voltage
IC702	AN6914	Charging Det.
TRANSISTOS		
Q701	2SD1110	Power Driver
Q702	2SB761	Switching & LED Drive
Q703,704,707	2SB641	Charging Mode
Q705,706	2SD636	Det.
DIODES		
D701 ⚠	SVDS5VB10	Rectifier
D703,706 Ⓢ	MA162A	Rectifier
D704,705	SVDPR5531K	Power & Charging Indicator
THERMISTOR		
TH701	ERTD2FHL332S	3.3kΩ
VARIABLE RESISTOR		
VR701	EVN38CA00B13	Output Voltage Adj.,1kΩ(B)

Ref. No.		Part No.	Description
SWITCHES			
S701		ESD14184	Recording Selector
S702	⚠	ESB827S	Power
TRANSFORMER			
T701	⚠	SLT66PU35A	Power Transformer
FUSE			
F701	⚠	XBA1F10NU14	125V,1A

- **Main unit**

Ref. No.		Part No.	Description
CABINET and CHASSIS PARTS			
1		SSAC101N01A	Front Panel Ass'y
2		SBN1085-4	Knob,Phones Level & Rec Blance
3		SSKT101N03	Knob,Rec Level
4		VGT0272	Knob,Indicator,Playback Mode & Playback Mute
5		SSKT101N01E	Button,Rec Muting
6		SSQA101N01	Spring,Rec Muting Button
7		SSKT101N02	Button,Power
8		SSAC101N04E	Cabinet Ass'y
9		VGU0497	Button,Batt Eject
10		VMB0967	Spring,Batt Eject Button
11		SSGZ101N01	Rubber,FL
12		VMSS0277	Bracket,Shoulder Strap
13		VGKS0430	Ornament,Left
14		VGKS0427	Ornament,Right
15		SSAC101N03	Bottom Board
16		VMG0211	Foot
17		SSUM101N05	Bracket,P.C.B
18		SSUM100N27	Clamper,Lead Wier
19		SSUM101N08	Latch
20		SSNP101N01	Plate
21		SJF3207-4N	Terminal,VIDEO IN/OUT
22		SJF3431-7SN	Terminal,LINE IN/OUT
23		SJF3431-8N	Terminal,VIDEO IN/OUT&COPY OUT
24		SSDK101M01	Socket,DIN(DC12V)
25		SSUP101N10	Bracket,DIN Socket
26		SSUP101P01	Bracket,Terminals
27		SSAC101N02	Rear Panel
28		SSUM101N07	Clamper,Lead Wire
29		SSUM101N04	Battery Case
30		VJF0144	Terminal,Battery
31		VMB0969	Spring,Battery Eject
32		VGQ0273	Stopper,Battery
33		VGU0312	Plate,Stoper
34		VMB0968	Spring,Stoper
35		VMA4972	Bracket,Stopper
36		VKF0111-1	Battery Cover
37		VMS2135-1	Shaft,Battery Cover
38		VMB0966-1	Spring,Battery Cover
39		VKC0051	Hinge
40		VMA5799	Plate,Hinge
41		SSNN101P02	Name Plate
42		SSDJ2317010	Jack,Mic
43		SSDJ2317020	Jack,Head Phones
45		SSUZ101N10	Spacer,Battery Eject Button
46		SSUM100N24	Spacer,
47		SFGZQ11N01	Spacer,Rec Mute LED
48		SSKK101N01	Filter,FL
SCREWS			
N1	Ⓢ	XTV3+8BFN	Screw,+3X8
N2	Ⓢ	XTV3+6BFN	Screw,+3X6
N3	Ⓢ	XTN3+8BFZ	Screw,+3X8
N4	Ⓢ	XTN3+6B	Screw,+3X6
N5		SSXG101N01	Screw,
N6	Ⓢ	XTB3+6BFZ	Screw,+3X6
N7	Ⓢ	XTV3+18BFN	Screw,+3X18
N8	Ⓢ	XSS17+4FZ	Screw,+17X4
N9	Ⓢ	XSN26+4FZ	Screw,+26X4
N10		SFXG212-03	Screw

Ref. No.		Part No.	Description
WASHERS			
N14	Ⓢ	XWG3FZ	Washer,φ3 (4)
N15	Ⓢ	XWA26BFZ	Washer,φ26 (2)
N16		SSXW101N01	Washer (2)
NUTS			
N17	Ⓢ	XNS8	Nut,φ8 (2)
N18	Ⓢ	XNS7	Nut,φ7 (1)
N19		SSXN101N01	Nut (2)
N20	Ⓢ	XNS12	Nut,φ12 (1)
CONNECTORS			
①		SSDJ101N01E	Connector Ass'y, BT151←→JA3 (1)
②		SSDJ101N02E	Connector Ass'y, F3←→SW P.C.B (1)
③		SSDJ101N03E	Connector Ass'y, F18←→RM P.C.B (1)
④		SSDJ101N04E	Connector Ass'y, A2←→PL P.C.B (1)
⑤		SSDJ101N05E	Connector Ass'y, F13←→BT152 (1)
⑥		SSDJ101N06E	Connector Ass'y, F6←→P.C.B. (1)
⑦		SSDJ101N07E	Connector Ass'y, F8←→BT108 (1)
⑧		SSDJ101N08E	Connector Ass'y, F15←→P P.C.B. (1)
⑨		SSDJ101N09E	Connector Ass'y, C3←→P P.C.B. (1)
⑩		SSDJ101N10E	Connector Ass'y, C1←→BT404 (1)
⑪		SSDJ101N13E	Connector Ass'y, JA5←→A8 (1)
⑫		SSDJ101N14E	Connector Ass'y, F5,12←→BT208 (1)
⑬		SSDJ101N15E	Connector Ass'y, F7←→BT206 (1)
⑭		SSDJ101N16E	Connector Ass'y, F1←→BT205 (1)
⑮		SSDJ101N17E	Connector Ass'y, F12←→BT209 (1)
⑯		SSDJ101N19E	Connector Ass'y, A6←→BT301 (1)
⑰		SSDJ101N20E	Connector Ass'y, JA2←→BT304 (1)
⑱		SSDJ101N21E	Connector Ass'y, F17←→BT307 (1)
⑲		SSDJ101N22E	Connector Ass'y, D2←→BT306 (1)
⑳		SSDJ101N23E	Connector Ass'y, D1←→BT302 (1)
㉑		SSDJ101N24E	Connector Ass'y, D3←→BT303 (1)
㉒		SSDJ101N25E	Connector Ass'y, X2←→BT305 (1)
㉓		SSDJ101N27E	Connector Ass'y, V308←→BT401 (1)
㉔		SSDJ101N28E	Connector Ass'y, F2←→BT403 (1)
㉕		SSDJ101N29E	Connector Ass'y, X1←→BT402,406,407 (1)
㉖		SSDJ101N30E	Connector Ass'y, C1←→BT404 (1)
㉗		SSDJ101N31E	Connector Ass'y, A3←→BT405 (1)
㉘		SSDJ101N32E	Connector Ass'y, A5←→JA4 (1)
㉙		SSDJ101N33E	Connector Ass'y, A1←→BT202,203 (1)
㉚		SSDJ101N35E	Connector Ass'y, A4←→BT204 (1)
㉛		SSDJ101N36E	Connector Ass'y, A7←→BT207 (1)
㉜		SSDJ101N41A	Connector Ass'y, F10←→F20 (1)
㉝		SSDJ101N42A	Connector Ass'y, F11←→F21 (1)
㉞		SSDJ101N43A	Connector Ass'y, F9←→F19 (1)
㉟		SSDJ101N11E	Connector Ass'y, F4←→SW P.C.B. (1)
㊱		SSDJ101N34E	Connector Ass'y, JA1←→V309 (1)
PACKING PARTS			
P1[M]		SSHP101M01	Carton Box (1)
P1[MC]		SSHP101C01	Carton Box (1)
P2		SSHH101N01	Pad,Front Upper Side (1)
P3		SSHH101N02	Pad,Front Lower Side (1)
P4		SSHH101N03	Pad,Rear Upper Side (1)
P5		SSHH101N04	Pad,Rear Lower Side (1)
P6		SSHD101N01	Parts Box,Accessories (1)
P7		SPP193	Polyethylen Bag, Main Unit (1)
P8		SFYF20A40	Polyethylen Bag, AC Power Unit (1)
P9		SEYF15A30	Polyethylen Bag, Pin Cords (1)
P10		SPP189	Polyethylen Bag, Sholder Strap & Cords (AC Power Unit) (2)

Ref. No.		Part No.	Description
ACCESSORIES			
A1[M]		SSNU101M01	Instruction Book (1)
A1[MC]		SSNU101CO1E	Instruction Book (1)
A2		VYCS0133	Shoulder Strap (1)
A3		SSDH101N01	Line Cord (2)
A4		SSDH101N02	Video Cord (2)

- **AC power unit**

Ref. No.		Part No.	Description
CABINET and CHASSIS PARTS			
1		SSAC101N50E	Front Panel Ass'y (1)
2		VGT0272	Knob,Recording (1)
3		SSKT101N02	Knob,Power (1)
4		SSAC101N51	Cabinet (1)
5[M]		SSNN101M50	Name Plate (1)
5[MC]		SSNN101C50	Name Plate (1)
6		SSEZ101N50	Bushing,DC cord (1)
7		SSDJ101M50	DC Cord (1)
8	⚠Ⓢ	RJA9Y	AC Cord (1)
9		SSUM100N28	Bushing,AC Cord (1)
10		SSDJ101N51	Multi Cable (1)
11		SSUK101P51	Rear Panel (1)
12		SJF3057-IN	Terminal (1)
13		SJT345	Holder,Fuse (2)
14		SSUK101N50	Chassis (1)
15		SSUZ101N50	Foot (4)
17		SHR401-2	Latch,Insulator (1)
18		SSUZ101N51	Insulator,Power P.C.B. (1)
19		SFDC109N01	Sheet,Power Transistor (1)
21		SSUP101N53	Bracket,Front Panel (2)
SCREWS			
N1	Ⓢ	XTV3+10BFN	Screw,+3X10 (4)
N2	Ⓢ	XTS3+8B	Screw,+3X8 (2)
N3	Ⓢ	XTB3+6BFZ	Screw,+3X6 (5)
N4	Ⓢ	XTB3+8BFZ	Screw,+3X8 (1)
N5	Ⓢ	XTV3+8BFN	Screw,+3X8 (4)
N6	Ⓢ	XTN4+8BFZ	Screw,+4X8 (4)
N7	Ⓢ	XTN3+6BFZ	Screw,+3X6 (2)
N8	Ⓢ	XSN3+14S	Screw,+3X14 (1)
WASHERS			
N9	Ⓢ	XWE3	Washer,φ3 (1)
N10	Ⓢ	XWA3B	Washer,φ3 (1)
NUT			
N11	Ⓢ	XNG3ES	Nut,φ3 (1)

■ REPAIR KNOBS (CUTTING OFF THE UNNECESSARY PART)

The indicator switch, playback mode, playback muting and recording switch (AC power unit) knobs (VGT0272) are the parts supplied by Video Division. So, when they are used on this unit, cut off the unnecessary part by use of nippers, etc. as shown here.



■ EXPLODED VIEWS

- **Main unit**



T.C. Corp
10 North Main St
Wharton NJ 07885
www.servicemanuals.net

- **AC power unit**



■ RESISTORS & CAPACITORS

Notes: 1. Part numbers are indicated on most mechanical parts. Please use this part number for parts orders.
2. Important safety notice:
Components identified by ⚠ mark have special characteristics important for safety. When replacing any of these components use only manufacturer's specified parts.
3. The "Ⓢ" mark is service standard parts and may differ from production parts.
4. The unit of resistance is Ω(ohm).
K = 1000Ω , M = 1000kΩ
5. The unit of capacitance is μF (microfarad)
P = 10^{-6} μF

Numbering System of Resistor

Example

ERD	25	F	J	101
Type	Wattage	Shape	Tolerance	Value

ERX	2	AN	J	2R2
Type	Wattage	Shape	Tolerance	Value

Resistor Type		Wattage		Tolerance	
ERD	: Carbon	10	: 1/8W	F	: ± 1%
ERG	: Metal Oxide	25	: 1/4W	G	: ± 2%
ERO	: Metal Film	50	: 1/2W	J	: ± 5%
ERF	: Metal Film	1A	: 1W	K	: ± 10%
ERQ	: Fuse	2F	: 1/4W		
		12S	: 1/2W		
		3A	: 3W		

ERD2FCG □□□ → Fuse type carbon (1/4W)
ERD10TJ □□□ → Chip type carbon
ERO10MKG □□□ → Chip type metal film

Numbering System of Capacitor

Example

ECKD	1H	102	Z	F
Type	Voltage	Value	Tolerance	Peculiarity

ECEA	50	M	R47	R
Type	Voltage	Reculiarity use	Value	Special use

Capacitor Type		Voltage		Tolerance	
ECEA	: Electrolytic	OJ	: 6.3V	C	: ± 0.25pF
ECEB	: Electrolytic	1A	: 16V	G	: ± 2%
ECEA . . . N	: Non Polar Electrolytic	1C	: 16V	J	: ± 5%
ECCD	: Ceramic	16	: 16V	K	: ± 10%
ECCR	: Ceramic	1E	: 25V	M	: ± 20%
ECQM	: Polyester	25	: 25V	P	: +100%, −0%
ECQP	: Polypropylene	1H	: 50V	Z	: +80%, −20%
ECES	: Electrolytic	1J	: 63V		
		50	: 50V		
		1VV	: 35V		
		ECQP1	: 100V		

ECUV1H ○○○ □□□ → Chip type ceramic
Value Peculiarity

● Main unit

Ref. No.		Part No.	Value
RESISTORS			
R101,102	⚠	ERQ12HKR22	0.22
R103	Ⓢ	ERD25FJ121	120
R104	⚠	ERD2FCG100	10
R105	Ⓢ	ERX1ANJ2R7	2.7
R106,107	Ⓢ	ERD25FJ561	560
R108	Ⓢ	ERD25TJ223	22K
R109	Ⓢ	ERD25FJ561	560
R110	Ⓢ	ERD25FJ472	4.7K
R111	Ⓢ	ERD25FJ103	10K
R112	Ⓢ	ERD25TJ223	22K
R113	Ⓢ	ERD25TJ154	150K
R114	Ⓢ	ERD25FJ272	2.7K
R115	Ⓢ	ERD25TJ823	82K
R116	Ⓢ	ERD25FJ472	4.7K
R117	Ⓢ	ERD25TJ823	82K
R118	Ⓢ	ERD25FJ103	10K
R119,120	Ⓢ	ERD25FJ472	4.7K
R121	Ⓢ	ERD25TJ473	47K
R122	Ⓢ	ERD25FJ472	4.7K
R123	Ⓢ	ERD25TJ104	100K
R124,125		ERD10TLJ473U	47K
R126		ERD10TLJ103U	10K
R127	Ⓢ	ERD25FJ561	560
R131,132	Ⓢ	ERD25FJ561	560
R140,141		ERG1ANJR68	0.68
R151,152		ERD10TLJ561U	560
R153,154		ERD10TLJ473U	47K
R155,156		ERD10TLJ221U	220
R157,158		ERD10TLJ332U	3.3K
R159,160		ERD10TLJ332U	3.3K
R161,162		ERD10TLJ332U	3.3K
R163,164		ERD10TLJ221U	220
R165,166		ERD10TLJ223U	22K
R167,168		ERD10TLJ103U	10K
R169,170		ERD10TLJ124U	120K
R171	⚠	ERD2FCG470	47
R172	Ⓢ	ERD25FJ102	1K
R173,174		ERD10TLJ124U	120K
R175,176		ER010MKF4640	464
R177,178		ER010MKF2001	2K
R179,180		ER010MKF2431	2.43K
R181,182		ERD10TLJ124U	120K
R183,184	Ⓢ	ER025CKF1801	1.8K
R185,186		ER010MKF1001	1K
R187,188		ERD10TLJ272U	2.7K
R189,190		ERD10TLJ272U	2.7K
R191,192		ERD10TLJ124U	120K
R193,194		ER010MKF2431	2.43K
R195,196		ER010MKF3922	39.2K
R197,198	Ⓢ	ER025CKF1102	11K
R199,200		ER010MKF3922	39.2K
R201,202	Ⓢ	ER025CKF3601	3.6K
R203,204		ERD10TLJ223U	22K
R205,206		ERD10TLJ224U	220K
R207,208		ERD10TLJ332U	3.3K
R209,210		ERD10TLJ151U	150
R211,212		ERG12SJ120J	12
R213,214		ERD10TLJ102U	1K
R215		ERD10TLJ473U	47K
R217		ERD10TLJ272U	2.7K
R218		ERD10TLJ103U	10K
R219		ERD10TLJ272U	2.7K
R220,221		ERD10TLJ221U	220
R222,223		ERD10TLJ473U	47K
R224		ERD10TLJ103U	10K
R225		ERD10TLJ473U	47K
R226		ERD10TLJ103U	10K
R227		ERD10TLJ473U	47K
R228,229		ERD10TLJ124U	120K
R230,231		ERD10TLJ472U	4.7K
R232,233		ERD10TLJ103U	10K
R234		ERD10TLJ332U	3.3K
R235		ERD10TLJ272U	2.7K
R236		ERD10TLJ474U	470K
R237		ERD10TLJ103U	10K
R238		ERD10TLJ473U	47K
R239,240		ERD10TLJ472U	4.7K
R241		ERD10TLJ223U	22K
R242		ERD10TLJ102U	1K
R243	Ⓢ	ERD25FJ3R3	3.3
R301	Ⓢ	ERD25FJ820	82
R302	Ⓢ	ERD25FJ472	4.7K
R303	Ⓢ	ERD25TJ223	22K
R304	Ⓢ	ERD25FJ472	4.7K
R305	Ⓢ	ERD25FJ222	2.2K
R306	Ⓢ	ERD25FJ272	2.7K
R307,308	Ⓢ	ERD25FJ102	1K
R309,310	Ⓢ	ERD25FJ472	4.7K
R311	Ⓢ	ERD25TJ393	39K
R312	Ⓢ	ERD25FJ472	4.7K
R313	Ⓢ	ERD25FJ122	1.2K
R314	Ⓢ	ERD25FJ272	2.7K
R315	Ⓢ	ERD25TJ183	18K
R316	Ⓢ	ERD25FJ472	4.7K
R317	Ⓢ	ERD25TJ153	15K
R318	Ⓢ	ERD25FJ680	68
R319	Ⓢ	ERD25FJ472	4.7K
R320	Ⓢ	ERD25TJ153	15K
R321	Ⓢ	ERD25FJ472	4.7K
R322	Ⓢ	ERD25FJ822	8.2K
R323	Ⓢ	ERD25FJ682	6.8K
R324	Ⓢ	ERD25FJ103	10K
R325	Ⓢ	ERD25TJ223	22K
R326,327	Ⓢ	ERD25FJ472	4.7K
R328	Ⓢ	ERD25TJ223	22K
R329,330	Ⓢ	ERD25TJ153	15K
R331,332	Ⓢ	ERD25FJ102	1K
R335	Ⓢ	ERD25FJ103	10K
R336	Ⓢ	ERD25FJ472	4.7K
R337	Ⓢ	ERD25FJ222	2.2K
R338	Ⓢ	ERD25FJ822	8.2K
R339	Ⓢ	ERD25TJ273	27K
R340	Ⓢ	ERD25FJ222	2.2K
R344	Ⓢ	ERD25TJ153	15K
R345	Ⓢ	ERD25FJ102	1K
R346,347	Ⓢ	ERD25TJ102	1K
R348	Ⓢ	ERD25FJ272	2.7K
R349,350	Ⓢ	ERD25FJ102	1K
R351	Ⓢ	ERD25FJ272	2.7K
R352,353	Ⓢ	ERD25FJ103	10K
R354	Ⓢ	ERD25FJ103	10K
R355	Ⓢ	ERD25FJ102	1K
R356	Ⓢ	ERD25TJ393	39K
R357	Ⓢ	ERD25TJ124	120K
R358	Ⓢ	ERD25TJ224	220K
R359	Ⓢ	ERD25TJ183	18K
R360	Ⓢ	ERD25FJ103	10K
R361	Ⓢ	ERD25FJ102	1K
R363	Ⓢ	ERD25TJ223	22K
R364	Ⓢ	ERD25FJ561	560
R365	Ⓢ	ERD25TJ104	100K
R366	Ⓢ	ERD25FJ103	10K
R367,368	Ⓢ	ERD25TJ473	47K
R369	Ⓢ	ERD25TJ473	47K
R370	Ⓢ	ERD25FJ103	10K
R371,372	Ⓢ	ERD25TJ473	47K
R373	Ⓢ	ERD25TJ473	47K
R374,375	Ⓢ	ERD25TJ104	100K
R376,377	Ⓢ	ERD25TJ104	100K
R378	Ⓢ	ERD25TJ104	100K
R379	Ⓢ	ERD25TJ183	18K
R381	Ⓢ	ERD25FJ103	10K
R382	Ⓢ	ERD25FJ122	1.2K
R383	Ⓢ	ERD25TJ183	18K
R384	Ⓢ	ERD25FJ102	1K
R385	Ⓢ	ERD25FJ152	1.5K
R386	Ⓢ	ERD25TJ153	15K
R387	Ⓢ	ERD25TJ104	100K
R388	Ⓢ	ERD25FJ103	10K
R389	Ⓢ	ERD25FJ272	2.7K
R390	Ⓢ	ERD25TJ473	47K
R391	Ⓢ	ERD25FJ102	1K
R393	Ⓢ	ER025CKF2203	220K
R394	Ⓢ	ERD25FJ103	10K
R395	Ⓢ	ERD25TJ473	47K
R396	Ⓢ	ERD25FJ222	2.2K
R397	Ⓢ	ERD25FJ102	1K
R398	Ⓢ	ERD25FJ222	2.2K
R399	Ⓢ	ERD25TJ153	15K
R401,402		ER010MKF1502	15K
R403,404		ER010MKF1502	15K
R405,406		ERD10TLJ103U	10K
R407,408		ER010MKF1101	1.1K
R409,410		ER010MKF4021	4.02K
R411,412		ER010MKF1101	1.1K
R413		ER010MKF4021	4.02K
R414		ER010MKF7321	7.32K
R415,416		ER010MKF4751	4.75K
R417,418		ER010MKF4321	4.32K
R419,420		ER010MKF4320	432
R421,422		ER010MKF1501	1.5K
R423		ER010MKF1000	100
R424		ER010MKF2800	280
R425		ER010MKF4640	464
R426		ER010MKF6340	634
R427		ER010MKF1101	1.1K
R428		ER010MKF2431	2.43K
R429		ERD10TLJ102U	1K
R430,431		ERD10TLJ151U	150
R432,433		ERD10TLJ151U	150
R434		ERD10TLJ124U	120K
R435,436		ERD10TLJ473U	47K
R437,438		ERD10TLJ472U	4.7K
R439		ERD10TLJ473U	47K
R440		ERD10TLJ104U	100K
R441		ERD10TLJ472U	4.7K
R442		ERD10TLJ151U	150
R443		ERD10TLJ473U	47K
R444		ERD10TLJ474U	470K
R445		ERD10TLJ103U	10K
R446		ERD10TLJ472U	4.7K
R447		ERD10TLJ103U	10K
R448		ERD10TLJ472U	4.7K
R449		ERD10TLJ223U	22K
R450		ERD10TLJ224U	220K
R451		ERD10TLJ473U	47K
R452		ERD10TLJ474U	470K
R453		ERD10TLJ103U	10K
R454		ERD10TLJ103U	10K
R455,456	Ⓢ	ERD25FJ152	1.5K
R457	Ⓢ	ERD25FJ152	1.5K
R461		ERD10TLJ4R7U	4.7
R462,463		ERD10TLJ221U	220
R464,465		ERD10TLJ103U	10K
R466		ERD10TLJ473U	47K
R467		ERD10TLJ272U	2.7K
R468		ERD10TLJ683U	68K

Ref. No.		Part No.	Value
R469,470		ERD10TLJ103U	10K
R471,472		ERD10TLJ224U	220K
R473		ERD10TLJ224U	220K
R474		ERD10TLJ221U	220
R475		ERD10TLJ473U	47K
R476		ERD10TLJ104U	100K
R481	Ⓢ	ERD25TJ823	82K
R482	Ⓢ	ERD25TJ333	33K
R501	Ⓢ	ERD25TJ473	47K
R502	Ⓢ	ERD25TJ124	120K
R503	Ⓢ	ER025CKF4702	47K
R504	Ⓢ	ERD25TJ153	15K
R505	Ⓢ	ER025CKF4702	47K
R506	Ⓢ	ERD25TJ273	27K
R507	Ⓢ	ER025CKF1243	124K
R508	Ⓢ	ERD25TJ473	47K
R509	Ⓢ	ERD25TJ154	150K
R510	Ⓢ	ERD25TJ473	47K
R511	Ⓢ	ERD25TJ273	27K
R512	Ⓢ	ERD25TJ224	220K
R513,514	Ⓢ	ERD25FJ272	2.7K
R515,516	Ⓢ	ERD25FJ103	10K
R519,520	Ⓢ	ERD25FJ103	10K
R521	Ⓢ	ERD25FJ103	10K
R601,602		ERD10TLJ474U	470K
R603,604		ERD10TLJ153U	15K
R605,606		ERD10TLJ473U	47K
R607,608		ERD10TLJ473U	47K
R609,610		ERD10TLJ223U	22K
R611,612		ERD10TLJ124U	120K
R613,614		ERD10TLJ472U	4.7K
R615		ERD10TLJ103U	10K
R616		ERD10TLJ474U	470K
R619		ERD10TLJ472U	4.7K
R620		ERD10TLJ184U	180K
R621		ERD10TLJ474U	470K
R622,623		ERD10TLJ124U	120K
R624,625		ERD10TLJ472U	4.7K
R626		ERD10TLJ153U	15K
R627		ERD10TLJ473U	47K
R628		ERD10TLJ103U	10K
R629		ERD10TLJ223U	22K
R630		ERD10TLJ474U	470K
R631		ERD10TLJ224U	220K
R632		ERD10TLJ472U	4.7K
R633	Ⓢ	ER025CKF2202	22K
R634	Ⓢ	ER025CKF1302	13K
R635		ERD10TLJ103U	10K
R636		ERD10TLJ472U	4.7K
R637		ERD10TLJ223U	22K
R638		ERD10TLJ103U	10K
R641,642		ERD10TLJ104U	100K
R643,644	Ⓢ	ERD25TJ274	270K
R645,646		ERD10TLJ683U	68K
R647,648	Ⓢ	ER025CKF1002	10K
R649,650	Ⓢ	ER025CKF2153	215K
R651,652		ERD10TLJ104U	100K
R653,654		ERD10TLJ224U	220K
R655		ERD10TLJ124U	120K
R656		ERD10TLJ683U	68K
R657		ERD10TLJ124U	120K
R659		ERD10TLJ103U	10K
R661,662		ERD10TLJ223U	22K
R663,664		ERD10TLJ223U	22K
R665,666		ERD10TLJ103U	10K
R667,668		ERD10TLJ473U	47K
R669		ERD10TLJ124U	120K
R671,672		ERD10TLJ683U	68K
R673		ERD10TLJ103U	10K
R674,675		ERD10TLJ103U	10K
R676,677		ERD10TLJ103U	10K
R678		ERD10TLJ103U	10K
R679	△	ERD2FCG560	56
R680	Ⓢ	ERD25FJ100	10

● AC power unit

Ref. No.		Part No.	Value
RESISTORS			
R701	Ⓢ	ERD25FJ121	120
R702	△	ERD2FCG560	56
R703	Ⓢ	ERD25FJ122	1.2K
R704	Ⓢ	ERD25FJ472	4.7K
R705	Ⓢ	ERD25TJ473	47K
R706	△	ERF3AKR47	0.47
R707	Ⓢ	ERD25TJ683	68K
R708	Ⓢ	ERD25TJ123	12K
R709	Ⓢ	ERD25FJ102	1K
R710	Ⓢ	ERD25FJ182	1.8K
R711	Ⓢ	ERD25FJ121	120
R712	Ⓢ	ERD25FJ332	3.3K
R713	Ⓢ	ERD25TJ473	47K
R714,715	Ⓢ	ERD25FJ472	4.7K
R716	Ⓢ	ERD25TJ683	68K
R717	Ⓢ	ERD25FJ681	680K
R718	Ⓢ	ERD25FJ472	4.7K
R719	Ⓢ	ERD25FJ222	2.2K
R720	Ⓢ	ERD25FJ682	6.8K
R721	Ⓢ	ERD25TJ473	47K
R722,723	△Ⓢ	ERD50FJ681	680
R724	△	ERD2FCG101	100
R725	Ⓢ	ERD25TJ393	39K
R728	Ⓢ	ERD25FJ822	8.2K
R729	Ⓢ	ERD25FJ152	1.5K
R730	Ⓢ	ERD25TJ104	100K

● Main unit

Ref. No.		Part No.	Value
CAPACITORS			
C103,104	Ⓢ	ECKD1H103MD	0.01
C105	Ⓢ	ECEA1CS471	470
C106		ECEA1CF471	470
C107	Ⓢ	ECQM1H272JZ	0.0027
C108	Ⓢ	ECCD1H101K	100P
C109		ECEA1CF471	470
C110	Ⓢ	ECEA1CS471	470
C111	Ⓢ	ECEA1AF471	470
C112	Ⓢ	ECEA0JS471	470
C113		ECEA1CF471	470
C114	Ⓢ	ECEA1CS471	470
C115	Ⓢ	ECCD1H101K	100P
C116	Ⓢ	ECQM1H473JZ	0.047
C117	Ⓢ	ECCD1H101K	100P
C118		ECEA1AF471	470
C119	Ⓢ	ECEA0JS471	470
C120	Ⓢ	ECCD1H560K	56P
C121	Ⓢ	ECQM1H122JZ	0.0012
C122	Ⓢ	ECEA50ZR1	0.1
C123	Ⓢ	ECQM1H103JZ	0.01
C124	Ⓢ	ECEA1AS470	47
C125	Ⓢ	ECEA1AS101	100
C126	Ⓢ	ECQM1H223JZ	0.022
C131	Ⓢ	ECEB1CS222	2200
C132	Ⓢ	ECKD1H103MD	0.01
C133	Ⓢ	ECEB0JS472	4700
C134	Ⓢ	ECKD1H103MD	0.01
C135	Ⓢ	ECEB1CS222	2200
C136,137	Ⓢ	ECKD1H103MD	0.01
C138	Ⓢ	ECEB1AS222	2200
C139,140	△	ECEA1CN100S	10
C141	△	ECEA1CN100S	10
C151,152	△	ECEA1CN100S	10
C153,154		ECUV1H102MBM	0.001
C155,156		ECUV1H103MBM	0.01
C157,158		ECUV1H101KM	100P
C159,160	△	ECEA1CN100S	10
C161	Ⓢ	ECEA1CS221	220
C162	Ⓢ	ECEA1CS331	330
C163,164	△	ECEA1CN100S	10
C165,166		ECQP1303GZ	0.03
C167,168		ECQP1202GZ	0.002
C169,170	△	ECEA1EN3R3S	3.3
C171,172		ECQP1392GZ	0.0039
C173,174	△	ECEA1CN330S	33
C175,176		ECUV1H102MBM	0.001
C177,178	△	ECEA1EN3R3S	3.3
C179,180	Ⓢ	ECEA1AS470	47
C181,182		ECUV1H471KM	470P
C183,184		ECUV1H103MBM	0.01
C185,186	Ⓢ	ECEA1AS470	47
C187,188	Ⓢ	ECQM1H683JZ	0.068
C189	Ⓢ	ECEA1AS101	100
C190	Ⓢ	ECEA0JS471	470
C191,192	△	ECEA1HN010S	1
C193	Ⓢ	ECKD1H103MD	0.01
C194	Ⓢ	ECEA16M6R8	6.8
C195	Ⓢ	ECEA0JS471	470
C196	Ⓢ	ECEA50Z1	1
C197		ECUV1H103MBM	0.01
C198,199		ECUV1H223MBM	0.022
C200,201	Ⓢ	ECEA1ES470	47
C202	Ⓢ	ECEA50Z1	1
C203	Ⓢ	ECEA1AS101	100
C204,205		ECUV1H223MBM	0.022
C206	Ⓢ	ECEA1CS100	10
C207,208	Ⓢ	ECEA1AS101	100
C209	△	ECEA1HN010S	1
C301,302	Ⓢ	ECEA1ES220	22
C303	Ⓢ	ECEA1ES220	22
C304	Ⓢ	ECCD1H470K	47P
C305	Ⓢ	ECEA50Z2R2	2.2
C306	Ⓢ	ECCD1H181K	180P
C307	Ⓢ	ECQM1H122JZ	0.0012
C308		ECCR1H561J	560P
C309	Ⓢ	ECCD1H101K	100P
C310	△	ECEA1HN010S	1
C311	Ⓢ	ECQM1H103JZ	0.01
C312	Ⓢ	ECQM1H332JZ	0.0033
C316,317	Ⓢ	ECEA50ZR22	0.22
C318	Ⓢ	ECEA1AS470	47
C319	Ⓢ	ECQM1H103JZ	0.01
C320	Ⓢ	ECCD1H101K	100P
C321	Ⓢ	ECEA25Z4R7	4.7
C322,323	Ⓢ	ECKD1H103MD	0.01
C324,325	Ⓢ	ECEA1AS101	100
C326,327	Ⓢ	ECKD1H103MD	0.01
C328,329	Ⓢ	ECKD1H103MD	0.01
C332	Ⓢ	ECEA1AS101	100
C333	Ⓢ	ECKD1H103MD	0.01
C335		ECQP1154JZ	0.15
C336		ECCR1H681J	680P
C337	Ⓢ	ECEA1CS330	33
C338	Ⓢ	ECEA1CS100	10
C401,402	△	ECEA1CN470S	47
C403,404		ECCR1H471J	470P
C405,406		ECQP1102GZ	0.001
C407,408		ECCR1H471J	470P
C409,410	Ⓢ	ECKD1H152KB	0.0015
C411	Ⓢ	ECKD1H103MD	0.01
C412,413	Ⓢ	ECEA0JS471	470
C414,415	Ⓢ	ECKD1H103MD	0.01
C416		ECUV1H223MBM	0.022
C417	Ⓢ	ECEA1AS470	47
C418		ECUV1H471KM	470P
C419,420		ECCR1H470J	47P
C421		ECQP1682GZ	0.0068
C422	△	ECEA1AN220S	22
C423	Ⓢ	ECEA50Z1	1
C424	Ⓢ	ECEA1CS100	10
C425	Ⓢ	ECEA50ZR47	0.47
C426,427		ECUV1H223MBM	0.022
C428	Ⓢ	ECEA0JS101	100
C429	Ⓢ	ECEA25Z4R7	4.7
C430		ECUV1H223MBM	0.022
C431	Ⓢ	ECEA0JS471	470
C432,433	Ⓢ	ECKD1H103MD	0.01
C434,435	Ⓢ	ECKD1H103MD	0.01
C436,437	Ⓢ	ECKD1H103MD	0.01
C438,439	Ⓢ	ECKD1H103MD	0.01
C440,441	Ⓢ	ECKD1H103MD	0.01
C442,443	Ⓢ	ECKD1H103MD	0.01
C444,445	Ⓢ	ECKD1H103MD	0.01
C446	Ⓢ	ECKD1H103MD	0.01
C447	Ⓢ	ECEA1HS100	10
C448	Ⓢ	ECEA1AS221	220
C449,450	Ⓢ	ECKD1H103MD	0.01
C451,452	Ⓢ	ECEA1ES101	100
C453,454	Ⓢ	ECKD1H103MD	0.01
C455,456	Ⓢ	ECEA1ES101	100
C457	Ⓢ	ECEA0JS331	330
C458	Ⓢ	ECCD1H101K	100P
C481,482	Ⓢ	ECQM1H102JZ	0.001
C483	Ⓢ	ECKD1H103MD	0.01
C501,502	Ⓢ	ECQM1H102JZ	0.001
C503,504	Ⓢ	ECQM1H102JZ	0.001
C505	Ⓢ	ECQM1H103JZ	0.01
C506	Ⓢ	ECEB1HSR47	0.47
C507		ECQP1102GZ	0.001
C508	Ⓢ	ECQM1H102JZ	0.001
C509	Ⓢ	ECEB2AS010	1
C510	Ⓢ	ECQM1H102JZ	0.001
C511	Ⓢ	ECQM1H103JZ	0.01
C512	Ⓢ	ECEB1CS101	100
C513,514	Ⓢ	ECEB50ZR22	0.22
C516		ECCF1H331J	330P
C517,518	△	ECEA1AN330S	33
C519,520	Ⓢ	ECEB1VS4R7	4.7
C521	Ⓢ	ECKD1H103MD	0.01
C522	Ⓢ	ECEA1AS101	100
C523,524	Ⓢ	ECKD1H103MD	0.01
C525,526	Ⓢ	ECKD1H103MD	0.01
C527,528	Ⓢ	ECEB1AS470	47
C529		ECCF1H101J	100P
C530	Ⓢ	ECKD1H103MD	0.01
C601,602	Ⓢ	ECEA50Z1	1
C603,604	Ⓢ	ECQM1H102JZ	0.001
C605,606	Ⓢ	ECEA50M3R3R	3.3
C607	Ⓢ	ECEA50Z1	1
C608	Ⓢ	ECEA1HS100	10
C609	Ⓢ	ECEA1ES101	100
C611	Ⓢ	ECQM1H223JZ	0.022
C612	△	ECEA1CN100S	10
C613,614	Ⓢ	ECEA50ZR47	0.47
C615	Ⓢ	ECQM1H472JZ	0.0047
C616	Ⓢ	ECEA1HS100	10
C617,618		ECUV1H102MBM	0.001
C619	Ⓢ	ECEA1ES101	100
C620		ECUV1H103MBM	0.01
C621	Ⓢ	ECEA1ES470	47

● AC power unit

Ref. No.		Part No.	Value
CAPACITORS			
C701	Ⓢ	ECQM1H683JZ	0.068
C702		ECES1VV472S	4700
C703	Ⓢ	ECCD1H101K	100P
C705	Ⓢ	ECCD1H680K	68P
C706	Ⓢ	ECEA50Z3R3	3.3
C707	Ⓢ	ECEA1ES101	100
C708,709	Ⓢ	ECEA50Z4R7	4.7

■ PRINTED CIRCUIT BOARDS

● AC power unit Ground (Earth) line



V Video circuit



Circuit view on top of P.C.B.

X Synchronizing circuit





Notes.
IC523 ② to IC514 ②
IC523 ⑧ to IC514 ⑧
IC523 ⑨ to IC514 ⑨
IC523 ⑯ to IC514 ⑯

A Analog circuit



JA Input/output terminals



VJ Video input/output terminals



RV Recording level/balance volume



HV Phones level volume



PL Playback indicator







D Digital circuit

X P.C.B. terminal (X1, ⑧ pin)

X P.C.B. terminal (X1, ⑨ pin)

D2

V2 P.C.B. terminal (V310)

C Connection P.C.B.

P Power supply circuit

A P.C.B. terminal (A9)

• Fluorescent Display Tube (FL)



FL FL P.C.B.



SW Switch circuit



PS Power switch



RM REC muting switch



F Display circuit









■ HOW TO REPLACE CHIPS (Resistor, Capacitor and Jumper)

1. Unsolder from chip by using solder sucker.
2. Remove chip with tweezers by rotating it while removing solder as shown in **Fig. 20.**
3. Solder circuit board first and then solder chip in the direction of the arrow as shown in **Fig. 21.**

Notes:

1. Do not use chip again which is removed from printed circuit board.
2. Use lead wire with insulator for replacement instead of chip jumper.



Fig. 21



Fig. 20

- **Note for replacing chips**

1. Do not heat chips more than three (3) seconds.
2. Be careful not to damage the electrode of chips.
3. Use soldering iron (less than 60 W) and tweezers for replacing chips.

■ PLAYBACK MODE SELECTION

This lets you select the demodulation mode that is most suitable for the playback signal of the VCR being used.
Although there is no problem when the same VCR is used for recording and playback, it may be difficult to obtain the same sound quality when a different VCR is used for playback.
In such cases, playback quality can be optimized by using the playback mode switch and adjusting VCR tracking.

1. Turn on the power on connected equipment and begin playback.
2. Set the indicator switch to "tracking/batt".
3. Watch the tracking check scale/indicator and switch the tracking mode back and forth between "1" and "2".
4. Choose the position that gives the furthest indication to the right.
   As a rule, optimum results will be obtained if the selector is set to "1" for VCR's like the PV-5000 which have an SLP (extended play) mode.
   For greatest effectiveness, perform tracking adjustment along with playback mode selection.

Note:

Other display panel indications go out when the indicator switch is set to "tracking/batt".

■ PACKING

1. Put the main unit into polyethylene bag, and tape its opening.



2. Put the cord of AC power unit into polyethylene bag, and the unit into bag.



3. Package in following procedure.



4. Seal the top with adhesive tape.
   * Use gum tape or adhesive cloth tape of 50 mm wide at least.



5. For the edges, first fold the flap "a" and then flap "b" and staple. Remember to staple only flap "b". (Use 15 or 16 mm staple)

* Stapling positions are shown below.



- **Accessories**

AC power unit (SH-V100)



Line cord x 2

Video cords x 2

Shoulder strap

• **AC power unit (SH-V100)**



• **Multi-terminal arrangement and signals**

No.	Signal	No.	Signal
1	Heater	8	Serial lock II [Pulse amplitude 5V]
2	Power supply (12V)		
3	Earth	9	Serial signal [Pulse amplitude 5V]
4	Lug break charge control With lug . . . . 12V Without lug . . 5V Charge 0V	10	Image input
5	———	11	———
6	Earth	12	Earth
7	Channel lock Antenna changeover Normal. . . . . 5V Channel lock .2.5V Video. 0V	13	Video input
		RF	VHF output

• **Product for MC only**

FUSE REPLACEMENT

Symbol located near the fuse indicates fast operating type. For continued protection against fire hazard, replace with same type fuse. Refer to the symbol for fuse rating.

FUSIBLE REMPLACEMENT

Le symbole qui se trouve près du fusible singifie un fusible à action rapide. Pour une protection contiue contre les risques d'incendie, n'utiliser que des fusibles du même type. Se rapporter au symbole pour la valeur des fusibles.

• **Block diagram of IC701 (SVIμPC305C)**



■ SCHEMATIC DIAGRAM

(This schematic diagram may be modified at any time with the development of new technology.)

* Part No. with ✪ mark are not identical between regular part No. and repair part No. supplied.
So, when placing an order for repair parts, use that part No. in the replacement parts list of repair parts.
* For the wire connection in the schematic diagram, refer to "CIRCUIT BOARDS AND WIRING CONNECTION DIAGRAM" (P18).

Notes:

1. **S601** : Power switch in **"on"** position.
2. **S602** : Recording muting switch in **"off"** position.
3. **S603** : Indicator switch in **"level"** position.
level ⟷ tracking/batt
4. **S604** : Playback mode switch in **"1"** position.
1 ⟷ 2
5. **S605** : Playback muting switch in **"auto"** position.
auto ⟷ off
6. **S701** : Recording mode switch in **"digital audio"** position. (AC power unit)
digital audio ⟷ video
7. **S702** : Power switch in **"on"** position. (AC power unit)
8. The written voltage and waveform are the reference voltage and waveform in playback mode which are measured by DC electronic voltmeter (high impedance) and oscilloscope on the basis of earth line. Accordingly, the voltage value may include some error depending upon the internal impedance of DC electronic voltmeter (tester, etc.) and the set measured.
9. Playback signal lines ⟹ Recording signal lines
Mic signal lines ⟹ Positive (+B) voltage lines

IMPORTANT SAFETY NOTICE

The shaded area on this schematic diagram incorporates special features important for safety.
When servicing it is essential that only manufacturer's specified parts be used for the critical components in the shaded areas of the schematic.

■ TERMINAL GUIDE OF IC'S , TRANSISTORS AND DIODES



SV-100 SV-100

• Video circuit

DN74LS02	14 pin
DN74LS04	
DN74SL08	
DN74LS14	
MN4066B	
SVIHD74LS00P	
SVIHD74SL02P	
SVIHD74SL11P	
SVIHD74SL32P	
SVIHD74SL74P	
SVIHD74SL86P	
SVIHD74SL126	
SVITC4001BP	
SVITC4001BP	
SVITC40H074	
SVIUPD4066C	
SVIHD74SL123	16 pin
SVIHD74SL161	
SVISN74LS629	
SVIM74SL123P	
SVIM74SL160P	
SVISN74LS123	
SVITC40H004P	
SVIUPC494C	



SVILA4140A



2SB643, 2SC2377
2SD636, 2SD637
2SB641, 2SB642

2SD1271

SVILM360N



2SC2385

2SD1110

SVITC5081AP



2SC1328



2SB761

2SK301



MA150, OA90A

SVDS2K20H
SVDS3S3M
SVDERC81004H



SVIDPR5531K (Red)
SVIDPG5531KY (Green)



SVDS5VB10



MA1051, MA1056,
MA1075, MA1100,
MA1150, MA2240



MA26T0-A



Note: Value in ( ) are voltage with playback mode selector (S604) set to "2".

• Synchronizing circuit

• Input/output waveform of X1, X2 terminals.





• Analog circuit



• Digital circuit



• Power supply circuit (DC-DC converter)



• Terminal number of FL segment



• Display circuit

Note: Values in [ ] are voltages with indicator selector (S603) set to "tracking/batt."



T.C. Corp
10 North Main St
Wharton NJ 07885
www.servicemanuals.net

Printed in Japan
830501460 (H) TK